






SUDEXPRESS®
scale model trains

vossloh

Locomotivas Euro4000 / Locomotoras Euro4000
Euro4000 locomotives

Funções disponíveis / Funciones disponibles / Available functions

			
F0	luzes on/off	luzes on/off	lights on/off
F1	som on/off	sonido on/off	sound on/off
F2	buzina 2 toques	bocina 2 tonos	air horn 2 tones
F3	buzina 1 toque	bocina 1 tono	air horn 1 tone
F4	chiar em curva	chirrido en curva	curve squeal
F5	modo manobras on/off	modo maniobras on/off	switching mode on/off
F6	compressor ar comprimido	escape de aire comprimido	air compressor
F7	flange	flange	switch flange
F8	inércia on/off	inercia on/off	inercia on/off
F9	buzina curta	bocina corta	short air horn
F10	luz cabina on/off	luce cabina on/off	cabin light on/off
F11	libertação freio	escape de freno	brake release
F12	freno	freno	brake set
F13	luzes	luzes	lights
F14	luzes de cauda on/off	luzes rojas on/off	tail red lights on/off
F15	farol principal on/off	faro principal on/off	upper front light on/off





SUDEXPRESS[®]
scale model trains

vossloh

Locomotivas Euro4000 / Locomotoras Euro4000
Euro4000 locomotives

Parâmetros CV do motor / Parámetros CV del motor / Motor CV parameters

CV49	19
CV52	15
CV53	140
CV54	50
CV55	100
CV56	255
CV124	21

