



Como abrir la carrocería:

Para abrir este modelo y acceder al enchufe digital o al motor hay que quitar la carrocería. Para ello hay que introducir las uñas entre chasis y carrocería y tirar de la carrocería en los áreas de los bogies hacia fuera (izquierda y derecha al mismo tiempo) y levantar la carrocería.

How to open the body shell:

To open this model and access digital plug and motor you have to remove the body shell. To do this you have to carefully introduce your fingernails between chassis and body shell and pull the body shell in the area of the bogies outwards. This way the body shell can be released from the chassis.

LISTA DE RECAMBIOS / LIST OF SPARES

Número Number	Descripción Description	Ref. repuesto Spare part ref.
1	Caja eléctrica Electric box	ER2682/01
2	Pantógrafo Pantograph	ER7609
3	Set de aislantes pantógrafo Pantograph insulators set	ER2682/03
4	Accesorios techo Roof accessories	ER2641/04
5	Salida de aire Air exhaust	ER2641/05
6	Accesorios carrocería Bodyshell accessories	ER2641/06
9	Foco Front lighting	ER6906/01
10	Ventanas frontales Front windows	ER2641/10
13	Set de aislantes cable Wires isolators set	ER2641/13
22	Circuito impreso Printed circuit	ER2682/22
23	Led blanco dorado Golden white led	ER6961
24	Led rojo Red led	ER6962
27	Set conjunto luces Lighting set	ER6963
28	Motor Motor	ER6918
29	Cardan Cardan joint	ER6919
35	Topera Buffers holder	ER2641/35
36	Quitanieves extremo 2 Extreme snowplough 2	ER6928/01
37	Timonería Under-frame accessories	ER2641/37
38	Quitanieves extremo 1 Extreme snowplough 1	ER6929/01
39	Cobertura bogie 2 Bogie shell 2	ER6931/01
40	Cobertura bogie 1 Bogie shell 1	ER6932/01
41	Tapa sinfin Gear worm lid	ER6933
43	Sinfin Gear worm	ER6934
48	Contacto ruedas Wheel current pick up	ER6940
49	Bogie completo DC Complete DC bogie	ER6945/01
54	Conjunto de transmisión Transmission set	ER6941
55	Aro de adherencia Traction Tyre	ER6946
56	Rueda con aro DC Wheelset with tyre DC	ER6947
58	Rueda sin aro DC Wheelset withoth tyre DC	ER6949
60	Base bogie Bogie base	ER6951/01
61	Tornillos base bogie Bogie bottom screw	ER6965
66	Mangueras frontales Front hoses	ER2638/66
68	Bolsa de accesorios Accessories bag	ER2638/68